### **ASSIGNMENT - 8**

# NAME - DIPAN MONDAL ROLL - 002211001112 SEC - A3

The given task is to make a comparison between different rle method on multiple parameters. The given two methods are Method 1:

Compression Algorithm:

Step-1: Start on the first element of input.

Step -2: Initialize the values with count=1, k=0.


Step-3: Read the first element of input data1.

Step-4: As the value of K is \_0' it will print the input data1 and then it increments the K value to \_1'.


Step-5: Again it goes to step-3 takes the second data2 and next the checks the value of k

Step-6:As the value of k is 1 it now it will checks for whether data1=data2,if the data1=data2 it will increment the count value if not equal it prints the count value after the data1 value and again goes to step 2.

#### Method 2:



Data: We have used 2 b&w ,2 grayscale and 2 rgb images.









The data previously is not preprocessed to particular sizes. So we used data preprocessing to resize them

```
def
convert and resize(image name, width, height, output name):
  image = cv2.imread(image_name,
cv2.IMREAD GRAYSCALE)
  if image is None:
    print("Error: Image not found or unable to read!")
    return
  _, bw_image = cv2.threshold(image, 127, 255,
cv2.THRESH BINARY)
  # Resize the image
  resized image = cv2.resize(bw image, (width, height),
interpolation=cv2.INTER AREA)
  # Save the new image
  cv2.imwrite(output_name, resized_image)
  print(f"Black and white resized image saved as
{output name}")
image_name = "./data/b&w1.png"
output_name = "./data/b&w1_mod.png"
width=50
height=50
convert_and_resize(image_name,width,height,output_name)
image_name = "./data/b&w2.png"
output_name = "./data/b&w2_mod.png"
width=100
height=100
convert and resize(image name, width, height, output name)
```

```
def grayscale image process(input name, width, height,
output name):
  image = cv2.imread(input name,
cv2.IMREAD_GRAYSCALE)
  if image is None:
    print("Error: Image not found or unable to read!")
    return
  resized image = cv2.resize(image, (width, height),
interpolation=cv2.INTER AREA)
  cv2.imwrite(output name, resized image)
  print(f"Resized grayscale image saved as {output name}")
image name = "./data/gray1.png"
output name = "./data/gray1 mod.png"
width=200
height=200
grayscale image process(image name, width, height, output na
me)
image_name = "./data/gray2.png"
output_name = "./data/gray2_mod.png"
width=300
height=300
grayscale image process(image name, width, height, output na
me)
def rgb image process(input name, width, height,
output name):
  image = cv2.imread(input_name, cv2.IMREAD COLOR)
  if image is None:
    print("Error: Image not found or unable to read!")
    return
```

```
resized_image = cv2.resize(image, (width, height), interpolation=cv2.INTER_AREA)

cv2.imwrite(output_name, resized_image)
print(f"Resized RGB image saved as {output_name}")
image_name = "./data/rgb1.png"
output_name = "./data/rgb1_mod.png"
width=400
height=400
rgb_image_process(image_name,width,height,output_name)
image_name = "./data/rgb2.png"
output_name = "./data/rgb2_mod.png"
width=500
height=500
rgb_image_process(image_name,width,height,output_name)
```

After the pre processing is done we used the two methods mentioned earlier to implement the methods and make the comparison table.

Method 1 implementation:

#### The main method of rle enocde

```
def rle_encode(data):
    encoded = []
    count = 1
    k = 0
    for i in range(1, len(data)):
        if data[i] == data[i - 1]:
            count += 1
        else:
            encoded.append((data[i - 1], count))
            count = 1
        encoded.append((data[-1], count)) # Add the last sequence
    return encoded
```

### A helper function to process all the images:

```
def image_to_rle(image_path, mode='grayscale'):
    start_time = time.time()

if mode == 'bw':
    image = cv2.imread(image_path,
cv2.IMREAD_GRAYSCALE) # Convert to B/W
    image = np.where(image > 127, 255, 0).astype(np.uint8)
elif mode == 'grayscale':
    image = cv2.imread(image_path,
cv2.IMREAD_GRAYSCALE)
elif mode == 'rgb':
    image = cv2.imread(image_path, cv2.IMREAD_COLOR)
```

```
else:
    raise ValueError("Invalid mode. Choose from 'bw',
'grayscale', 'rgb'")
  original size = image.size # Total pixels
  if mode == 'rgb':
    flattened = image.reshape(-1, 3) # Flatten RGB
    encoded = [rle_encode(flattened[:, i]) for i in range(3)] #
RLE per channel
  else:
    flattened = image.flatten()
    encoded = rle encode(flattened)
save encoded(image path+" paper1 encoded.pkl",encoded)
  compressed size = sum(len(enc) for enc in encoded) * 2 #
Each (value, count) pair is stored
  compression ratio = (compressed size / original size) * 100
  space_saving = 100 - compression_ratio
  compression_time = (time.time() - start_time) * 1000 #
Convert to milliseconds
  return original size, compressed size, compression ratio,
space saving, compression time
Helper function to make the comparison table:
def evaluate_images(image_paths, modes=['bw', 'grayscale',
'rgb']):
  results = []
  for i in range(len(image paths)):
    image path=image paths[i]
```

```
mode=modes[i//2]
    orig_size, comp_size, comp_ratio, space_save,
comp time = image to rle(image path, mode)
    results.append([image path, mode, orig size, comp size,
comp ratio, space save, comp time])
  df = pd.DataFrame(results, columns=['Image', 'Mode',
'Original Size', 'Compressed Size', 'Compression Ratio (%)',
'Space Saving (%)', 'Compression Time (ms)'])
  return df
image paths = ['./data/b&w1 mod.png',
        './data/b&w2 mod.png',
        './data/gray1_mod.png',
        './data/gray2 mod.png',
        './data/rgb1 mod.png',
        './data/rgb2 mod.png']
df1=evaluate images(image paths)
```

# **Implementation of second method:**

#### Main method to encode rle

```
def bitwise_rle_encode(data):
    encoded = []
    count = 1
    prev = data[0]
    for i in range(1, len(data)):
        if data[i] == prev:
            count += 1
        else:
        encoded.append((prev, count))
```

```
prev = data[i]
       count = 1
  encoded.append((prev, count)) # Add last sequence
  return encoded
Helper method to process all the images:
def image to bitwise rle(image path, mode='grayscale'):
  start time = time.time()
  if mode == 'bw':
    image = cv2.imread(image_path,
cv2.IMREAD GRAYSCALE)
    image = np.where(image > 127, 255, 0).astype(np.uint8)
# Convert to B/W
  elif mode == 'grayscale':
    image = cv2.imread(image_path,
cv2.IMREAD GRAYSCALE)
  elif mode == 'rgb':
    image = cv2.imread(image_path, cv2.IMREAD_COLOR)
  else:
    raise ValueError("Invalid mode. Choose from 'bw',
'grayscale', 'rgb'")
  original size = image.size # Total pixels
  if mode == 'rab':
    flattened = image.reshape(-1, 3) # Flatten RGB
    with multiprocessing. Pool(3) as pool:
       encoded = pool.map(bitwise rle encode, [flattened[:, i]
for i in range(3)])
  else:
    flattened = image.flatten()
    encoded = bitwise rle encode(flattened)
```

```
save_encoded(image_path+"_paper2_encodes.pkl",encoded)
  compressed size = sum(len(enc) for enc in encoded) * 2 #
Each (value, count) pair
  compression ratio = (compressed size / original size) * 100
  space saving = 100 - compression ratio
  compression_time = (time.time() - start_time) * 1000 #
Convert to milliseconds
  return original size, compressed size, compression ratio,
space saving, compression time
Helper method to save the results:
def evaluate bitwise images(image paths, modes=['bw',
'grayscale', 'rgb']):
  results = []
  for i in range(len(image paths)):
    image_path=image_paths[i]
    mode=modes[i//2]
    orig size, comp size, comp ratio, space save,
comp time = image to bitwise rle(image path, mode)
    results.append([image path, mode, orig size, comp size,
comp ratio, space save, comp time])
  df = pd.DataFrame(results, columns=['Image', 'Mode',
'Original Size', 'Compressed Size', 'Compression Ratio (%)',
'Space Saving (%)', 'Compression Time (ms)'])
  return df
if name == " main ":
  image paths = ['./data/b&w1 mod.png',
        './data/b&w2 mod.png',
        './data/gray1 mod.png',
```

# **Results:**

### <u>Paper 1:</u>

	Image	Mode	Original Size	Compressed Size	Compression Ratio (%)	Space Saving (%)	Compression Time (ms)
0	./data/b&w1_mod.png	bw	2500	1068	42.720000	57.280000	21.638155
1	./data/b&w2_mod.png	bw	10000	2360	23.600000	76.400000	7.990360
2	./data/gray1_mod.png	grayscale	40000	134172	335.430000	-235.430000	106.009960
3	./data/gray2_mod.png	grayscale	90000	183616	204.017778	-104.017778	163.899183
4	./data/rgb1_mod.png	rgb	480000	728096	151.686667	-51.686667	1262.986660
5	./data/rgb2_mod.png	rgb	750000	1270360	169.381333	-69.381333	2613.003492

### Paper 2:

Image	Mode	Original Size	Compressed Size	Compression Ratio (%)	Space Saving (%)	Compression Time (ms)
./data/b&w1_mod.png	bw	2500	1068	42.720000	57.280000	0.000000
./data/b&w2_mod.png	bw	10000	2360	23.600000	76.400000	15.625000
./data/gray1_mod.png	grayscale	40000	134172	335.430000	-235.430000	109.400749
./data/gray2_mod.png	grayscale	90000	183616	204.017778	-104.017778	124.977589
./data/rgb1_mod.png	rgb	480000	728096	151.686667	-51.686667	2919.356108
./data/rgb2_mod.png	rgb	750000	1270360	169.381333	-69.381333	4229.779243